



Instructions for changing the Panel on Isotherm Cruise Refrigerators



Step 1: Remove screws from handle.



Step 2: Remove retainer from bottom of panel by starting at one end and carefully prying the piece free with a flat head screwdriver.



Step 3: Slide panel down and out of the frame.



Step 4: Slide new panel into frame, replace bottom retainer, and replace screws.